# ROXEL

# RGM350

Head-mounted e-sports wired headset User Manual

#### Dear user

Thank you for purchasing RGM350 foldable stereo wireless headphones.

#### ROXEL:

@2019 ROXEL, All rights reserved by ROXEL Limited registered in United Kingdom. The logo "ROXEL" is a trademark of ROXEL Limited.

#### Address

Roxel Limited Unit 11a Lakes Industrial Park Lower Chapel Hill Braintree Essex CM7 3RU

- support@roxel.co.uk ⊕ www.roxel.co.uk
- facebook.com/RoxelUK
- twitter.com/roxeluk

# instagram.com/roxel\_uk

Thank you for purchasing the model RGM350 Head-mounted e-sports wired headset. Pls read this manual before use.


## Accessories List

1X Headphone 1X User Manual 1X 3.5mm Connector





### Specifications



### Safety And Maintenance

Please read suggestions below in order understand the warranty clauses and prolong the lifespan of the product.

deform some plastic parts.

\*Keep the product dry, do not place in wet or humid circumstances. \*Avoid prolonged sun exposure and heat. High temperatures will shorten the lifespan of electronic components, damage battery and

If your product is not in working order, Please contact Roxel support team. (support@roxel.co.uk)

### Guarantee and After Sales Services

The conditions of guarantee are :

months quarantee period

\* Proof of purchase is required

replaced with a refurbished or repaired product.

Your RGM350 is guaranteed for a period of 12months from the date of

Subject to terms listed below , the guarantee will provide the repair of, at Roxel's or its agent's discretion to replace the device, or any component thereof, ( other than batteries), which is identified as faulty or below standard or as a result of inferior workmanship or materials. Products over 30 days old from the date of purchase maybe

\* The guarantee shall only apply to defects that occur within 12

\*Do not use the headphone in very low temperatures to avoid damage to PCB board.

\*Do not attempt to take the product apart.

\*Do not drop, force, misuse or immerse in water to avoid damage to inner electronic circuit.

\*Do not use chemical products to clean the item.

\*Do not scratch the surface with sharp items to avoid damaging the case and appearance.

\*Do not charge longer than 10 hours for prolonged lifespan.

\*The equipment is returned to ROXEL Ltd. or its agent as instructed

This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt adjustment or repair other than through approved agents.

This quarantee does not affect your statutory rights

