ROXEL

Dear user

Thank you for purchasing RX H600 - BT foldable, stereo wireless headphones.

ROXEL:

@2019 ROXEL. All rights reserved by ROXEL Limited registered in United Kingdom. The logo "ROXEL" is a trademark of ROXEL Limited.

Address
Roxel Limited
Unit 11a Lukes Industrial Park
Lower Chapel Hill
Braintree
Essex
CM7 3RU

support@roxel.co.uk
www.roxel.co.uk
facebook.com/RoxelUK
twitter.com/roxeluk
instagram.com/roxel_uk

Inspire your Soul

H600BT
Wireless Stereo Headphones
User Manual

1

Accessories List

1X Wireless Headphones
1X User Manual
1X USB Charging Cable
1X Aux Cable



2

Overview Of Headset



3

How To Use

Turning On/Off

ON: Long press the R MFB for about 3 seconds until the blue LED indicator light turns on.

Off: Long press the R MFB for about 4 seconds until the LED light turns off.

Pairing

Ensure the headset is charged sufficiently

Turn on the the headset when you paire the headset with a device for the first time after you bought it or after initialized the headset (the headset has no pairing information), The headset enters pairing mode automatically.

When you pair a second or subsequent device (the headset already has pairing information for other devices), press and hold the (power) button for about 5 seconds to enter pairing mode manually.

Make sure Bluetooth function on your device is turned on, Find 'Roxel H600BT' on the list and click to connect, Solid blue LED light on the headset indicates that it has successfully paired.

Once Bluetooth devices are paired, there is no need to pair them again, when within range the headset will automatically reconnect to the last device which it was connected to.

NOTE: If the headphone is not used within 5 minutes, the headphones will automatically turn off to save battery.

4

How To Use

Charging

- On the right earcup, carefully plug the micro USB cable into micro USB charging port and connect the other end of the cable to either a computer USB port or to a USB-compatible car or wall charger.
- Solid red LED light will appear to indicate when the headphone is charging.
- When charging is complete, the LED light will turn Blue.
- Charging time is approximately 2 hours.

5

How To Use

Bluetooth Version: V5.0
Profile Support: A2DP/AVRCP/HFP
Talk Time: 18 h
Music Play Time: 18 h
Charging Time: 2 h
Charging Voltage: 5V
Frequency Range: 2402MHz-2480MHz
Ambient Temperature: -10~45℃
Transmission Distance: 10m
Battery Capacity: 300mAh

Driver Specification

Driver Unit: 40 mm
Sensitivity: 108dB ± 3 dB
Impedance: 640 ± 15%
Frequency Response: 20-20000Hz

6

Safety And Maintenance

Please read suggestions below in order understand the warranty clauses and prolong the lifespan of the product.
*Keep the product dry, do not place in wet or humid circumstances.
*Avoid prolonged sun exposure and heat, High temperatures will shorten the lifespan of electronic components. damage battery and deform some plastic parts.
*Do not use the headphone in very low temperatures to avoid damage to PCB board.
*Do not attempt to take the product apart.
*Do not drop, force,misuse or immerse in water to avoid damage to inner electronic circuit.
*Do not use chemical products to clean the item.
*Do not scratch the surface with sharp items to avoid damaging the case and appearance.
*Do not charge longer than 10 hours for prolonged lifespan.

If your product is not in working order, Please contact Roxel support team. (support@roxel.co.uk)

7

Guarantee and After Sales Services

Your H600BT is guaranteed for a period of 12months from the date of purchase
Subject to terms listed below , the guarantee will provide the repair of, at Roxel's or its agent's discretion to replace the device,or any component thereof, (other than batteries), which is identified as faulty or below standard or as a result of inferior workmanship or materials.Products over 30 days old from the date of purchase maybe replaced with a refurbished or repaired product.
The conditions of guarantee are :

* The guarantee shall only apply to defects that occur within 12 months guarantee period

* Proof of purchase is required

*The equipment is returned to ROXEL Ltd, or its agent as instructed

This guarantee does not cover any faults or defects caused by accidents , misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt adjustment or repair other than through approved agents.

This guarantee does not affect your statutory rights

8